

SHOUT NANO 200

ATAK PLUGIN USER GUIDE Rev. D

11100 Endeavor Ct, STE 300, Manassas, VA, 20109, United States | Support@Naltec.com | +1 888-746-8867 | Naltec.com

SHOUT nano 200

ATAK Plugin Guide

Document Number: 451-25008-002D

Revision Date: 6/25/2026

© 2026 NAL Technologies, All Rights Reserved

LEGAL DISCLAIMER AND CONDITION OF USE

This document contains information for SHOUT nano 200 SBD trackers and accompanying accessories ("Product"), which is provided "as is." Reasonable effort has been made to make the information in this document reliable and consistent with specifications, test measurements and other information. However, NAL Research Corporation DBA NAL Technologies and its affiliated companies, directors, officers, employees, agents, trustees or consultants ("NAL Technologies") assume no responsibility for any typographical, technical, content or other inaccuracies in this document. NAL Technologies reserves the right in its sole discretion and without notice to you to change Product specifications and materials and/or revise this document or withdraw it at any time. User assumes the full risk of using the Product specifications and any other information provided. SHOUT nano 200 is not suitable for use in locations where children are likely to be present. Do not open or modify SHOUT nano 200 in any manner. All internal maintenance shall only be done by an NAL Technologies authorized service professional.

NAL Technologies makes no representations, guarantees, conditions or warranties, either express or implied, including without limitation, any implied representations, guarantees, conditions or warranties of merchantability and fitness for a particular purpose, non-infringement, satisfactory quality, non-interference, accuracy of informational content, or arising from a course of dealing, law, usage, or trade practice, use, or related to the performance or nonperformance of any products, accessories, facilities or services or information except as expressly stated in this guide and/or the Product and/or satellite service documentation. Any other standards of performance, guarantees, conditions and warranties are hereby expressly excluded and disclaimed to the fullest extent permitted by the law. This disclaimer and exclusion shall apply even if the express limited warranty contained in this guide or such documentation fails of its essential purpose.

In no event shall NAL Technologies be liable, whether in contract or tort or any other legal theory, including without limitation strict liability, gross negligence or negligence, for any damages in excess of the purchase price of the Product, including any direct, indirect, incidental, special or consequential damages of any kind, or loss of revenue or profits, loss of business, loss of privacy, loss of use, loss of time or inconvenience, loss of information or data, software or applications or other financial loss caused by the Product (including hardware, software and/or firmware) and/or the Iridium satellite, or arising out of or in connection with the ability or inability to use the Product (including hardware, software and/or firmware) and/or the Iridium satellite to the fullest extent these damages may be disclaimed by law and whether advised of the possibilities of such damages. NAL Technologies is not liable for any claim made by a third party or made by you for a third party.

This document contains NAL Technologies proprietary information which may not be used, reproduced, or disclosed without written approval from NAL Technologies.

© 2026 NAL Technologies, All Rights Reserved

REVISION HISTORY

Revision	Date	Description
A	11/07/2025	Formal Release
A.1	12/11/2025	Removed Broadcast
B	12/19/2025	Formal Release
B.1	1/21/2026	Added SOS feature
C	1/27/2026	Formal Release
C.1	6/25/2026	Content edits
D	6/25/2026	Formal Release

REFERENCE DOCUMENTS

Please email support@naltec.com for the latest revisions of the below Naltec documents.

Reference	Title	Revision
[1]	*SHOUT nano 200 User Guide*	D

© 2026 NAL Technologies, All Rights Reserved

TABLE OF CONTENTS

Legal Disclaimer and Condition of Use....3
Revision History....4
Reference Documents....4
Table of Contents....5
Table of Figures....6
Introduction....7
Device Overview....7
SHOUT nano 200....7
ATAK Plugin Interface....8
ATAK Symbols....8
Plugin Symbols....9
Installing the ATAK SHOUT Plugin....10
Pairing SHOUT nano 200 & ATAK Plugin....10
Using the ATAK SHOUT Plugin....12
Compose Message....12
Check Mailboxes....14
Manage Contacts....15
Location Tracking....16
Location Controls....18
Advanced Settings....18
Supported Operating Systems/Versions....19

© 2026 NAL Technologies, All Rights Reserved

TABLE OF FIGURES

Figure 1: SHOUT nano 200 external components 7
Figure 2: ATAK SHOUT Plugin interface 8
Figure 3: How to enable Bluetooth on SHOUT nano 200 10
Figure 4: Bluetooth connection on the ATAK SHOUT Plugin 11
Figure 5: SHOUT Device Manager window 11
Figure 6: How to compose and send a message 12
Figure 7: Inbox, outbox, and sent messages 14
Figure 8: View, edit, and delete contacts 15
Figure 9: Create a new contact 15
Figure 10: Using the map to view all connected devices 16
Figure 11: View individual asset location 16
Figure 12: Mesh neighbors with SOS-enabled device 17
Figure 13: Location Controls 18
Figure 14: Advanced settings and plugin settings 18
Figure 15: ATAK version 19

© 2026 NAL Technologies, All Rights Reserved

INTRODUCTION

This guide describes how to connect to and use NAL Technologies' (Naltec) ATAK SHOUT Plugin with SHOUT nano 200 Short Burst Data® (SBD®). The Android Team Awareness Kit (ATAK) SHOUT Plugin enables two-way, real-time communication to an individual contact or a group of devices.

DEVICE OVERVIEW

SHOUT nano 200

The lightweight SHOUT nano 200 device has an LCD display, an Iridium and GPS antenna, a belt clip, and buttons for the following capabilities: power/enter; up, down, left, and right screen navigation; and emergency/911. The USB-C interface port on the bottom of the device is for charging, firmware updates, data collection, and setting parameters using the Naltec SatTerm app.

Figure 1: SHOUT nano 200 external components

Simply hold the Power/Enter button for 5 seconds to turn the device off/on and awaken it from sleeping. **NOTE**: Upon waking up, the device will not display the Naltec splash screen.

For more information about using SHOUT nano 200, see the SHOUT nano 200 User Guide [1].

© 2026 NAL Technologies, All Rights Reserved

ATAK SHOUT Plugin Interface

At the top of the Plugin interface, access the toolbar and view important information such as satellite signal strength, number of connected mesh devices, battery level, and number of messages in your inbox and outbox.



Figure 2: ATAK SHOUT Plugin interface

ATAK SYMBOLS

Numbers 1-8 in the image above describe the ATAK symbols located at the top of the interface.

1) *Compass* – Used to control map orientation.
2) *Contacts* – Access contact list and choose communication methods with other users on the local network or TAK server.
3) *Overlay Manager* – Sorts map objects, files, and overlays into categories and subcategories.
4) *Maps & Favorites* – Lists the imagery loaded in the app.
5) *Point Dropper* – Enter locations of interest here. Select this symbol to place markers and other icons on the map, edit the data, and share the markers with other network members.
6) *Red X* – Determine coordinate and elevation data for a point on the map. Click the symbol to toggle the Red X into a movable state.
7) *Bloodhound* – Supports tracking and intercepting a map item. It enables you to select two points on the map, and/or map objects, and displays Range & Bearing information between the chosen tracker and the target.

© 2026 NAL Technologies, All Rights Reserved

8) *Menu* – Upon opening the app, click this symbol and choose the 'SHOUT TAK plugin' tile to navigate to the interface. This symbol also provides access additional capabilities, including geofencing, image gallery, and settings to change screen orientation.

PLUGIN SYMBOLS

Numbers 9-12 in the image above describe the Plugin symbols located at the top of the interface.

9) IRD - Indicates Iridium signal strength.

10) MESH – Displays number of mesh-connected devices. When this icon is clicked, a dialog with all mesh neighbors appears.

11) BAT – Shows battery percentage.

12) IN / OUT / SENT – Easily view the number of messages in your inbox, outbox, and sent box here. Click the symbols to be directed to those mailboxes.

© 2026 NAL Technologies, All Rights Reserved

INSTALLING THE ATAK SHOUT PLUGIN

Navigate to the Google Play Store and download the ATAK app and then the Plugin app. After installing both, click on the ATAK app and enable the Plugin using the ATAK menu and the ATAK Plugin button. **NOTE**: ICON can be placed on the ATAK screen to provide an alternative option to opening the Plugin.

PAIRING SHOUT NANO 200 & ATAK PLUGIN

Follow these steps to pair SHOUT nano 200 and the ATAK SHOUT Plugin:

1) Enable Bluetooth on your Android device
2) Enable Bluetooth on your SHOUT device
3) Pair in the Android device settings
4) Connect in the ATAK SHOUT Plugin

Enable Bluetooth pairing on SHOUT nano 200 by navigating to the *Home* screen > **BT Pairing** > **Enable BT** > **Enable**. If successful, a white Bluetooth icon appears indicating the SHOUT nano 200 is Bluetooth enabled. A green icon indicates it is connected to a Bluetooth device.

Figure 3: How to enable Bluetooth on SHOUT nano 200

On your Android, select the ATAK SHOUT Plugin app, then click the hamburger menu symbol at the top of the interface. Scroll down and choose the 'ATAK SHOUT Plugin' tile to access the interface.

Press the 'Scan/Connect' button to search for the device. A connected message will appear, and the Bluetooth *Connection Status* field displays the device IMEI number in green.

© 2026 NAL Technologies, All Rights Reserved



Figure 4: Bluetooth connection on the ATAK SHOUT Plugin

View, connect to, or unpair SHOUT devices here. Click the 'Scan for More' button to search for additional available devices.



Figure 5: SHOUT Device Manager window

© 2026 NAL Technologies, All Rights Reserved

USING THE ATAK SHOUT PLUGIN

Compose Message

Follow these steps to send a message to all or a select number of contacts.

Figure 6: How to compose and send a message

1) Scroll down the ATAK SHOUT Plugin interface and click the 'Compose Message' button located in the *Messaging* section.



2) In the Advanced SHOUT Message Composer window, type the message (there is a 230-character limit). Scroll down the window to add status reports, emergency information, operational updates, confirmations, or requests to your message.



© 2026 NAL Technologies, All Rights Reserved

3) Continue scrolling to select the desired send method, recipients for the message, and communication method. Press ‘Send Message’ when ready and a success message will appear.





© 2026 NAL Technologies, All Rights Reserved

Check Mailboxes

In *SHOUT Mailboxes*, see the messages in your inbox, outbox, and sent box. You can reply to, view, and delete messages in this section.



The symbols under the toolbar at the top of the interface show the number of messages in each mailbox. Click on the symbols to be directed to their respective boxes or simply scroll down the interface to access those sections.



Figure 7: Inbox, outbox, and sent messages

© 2026 NAL Technologies, All Rights Reserved

Manage Contacts

Click the 'List / Edit / Delete Contacts' button to make changes to existing contact information.



Figure 8: View, edit, and delete contacts

In the *Add Contact to SHOUT Device* section, complete the fields and then press the 'Add Contact' button to create a new recipient.



Figure 9: Create a new contact

© 2026 NAL Technologies, All Rights Reserved

Location Tracking

Use the map to view the location of all connected devices. The green rectangle with the letters 'SEC' denotes your connected SHOUT nano 200. The light blue triangle is the ATAK user marker populated by ATAK based on your cellular device's GPS or where you place yourself.

When plotted, mesh neighbors appear as blue rectangles with the letters 'SEC'. Sometimes, aged-out SHOUT or mesh neighbor markers from previous connections appear for a short period of time. These are indicated by a red and white cross.

Figure 10: Using the map to view all connected devices

Click on individual assets to see their location.



Figure 11: View individual asset location

© 2026 NAL Technologies, All Rights Reserved

Mesh neighbors with SOS enabled will display with a red symbol below their name on the map. You will also receive a notification.

To enable SOS on your specific device, please refer to the SHOUT nano 200 User Guide [1].



Figure 12: Mesh neighbors with SOS-enabled device

© 2026 NAL Technologies, All Rights Reserved

Location Controls

Disable location sharing and clear previous location updates under the *Location Controls* section.



Figure 13: Location Controls

Advanced Settings

Configure intervals for map marker visibility and status bar updates in *Advanced Settings*.



Figure 14: Advanced settings and plugin settings

© 2026 NAL Technologies, All Rights Reserved

Supported Operating Systems/Versions

The Naltec ATAK Plugin currently supports ATAK version 5.4.0

Figure 15: ATAK version

© 2026 NAL Technologies, All Rights Reserved

© 2026 NAL Technologies, All Rights Reserved. NAL Technologies and the NAL Technologies logos are registered trademarks of NAL Technologies and its affiliates. All other trademarks, service marks, and logos are the property of their respective holders, which have not endorsed, sponsored, or otherwise affiliated with NAL Technologies. Information is subject to change without notice.